

## TIMBER FOLDING DOORS

### TOE & HEEL DEVICE

#### UNGLAZED DOORS

If the door panels have been supplied unglazed it is recommended that you glaze the panels prior to installation by supporting the panels on a bench and inserting the sealed units so that the weight of the glass helps provide a positive seal against the external glazing tape. Fit the glazing beads ensuring positive sealing against the internal surface of the glass and use the pins supplied to fix in position.



#### GLAZED DOORS

##### Toe and Heel - Auto toe and heel device adjustment

1. In the top of each panel you will find a Pozi-Head screw bolt.
2. The doors panels will already be at their lowest point.
3. With the doors in the closed position, identify any panels that require lifting.
4. Open the doors so that you can get access to the auto toe and heel device at the top of the door panel
5. Wind the screw head clockwise, this will cause the corner of the door to rise.
6. Re-close the doors and check that they run parallel and evenly to the top and bottom tracks.
7. If they do not, then repeat as necessary.